



Remote Control Function

- ① Power on/off
- ② Video switchover
- ③ ◀ Analog decrease
- ④ ▶ Analog increase
- ⑤ Mode
- ⑥ Menu
- ⑦ Insulation sheet



Wiring Instruction




Preface

1. Do not try to open the covers, It is a high precision product.
2. Do not use organic solvent clear the covers, To avoid it peel off painting
3. Do not enforce to the lead wire, To avoid damage or poor connect.
4. Keep the product out of the dirty, direct sun, high temperature and humidity condition
5. Protect the product from fall down and shock.

4.3 Inch Rearview Mirror Monitor

Thanks for your support. To ensure long-term trouble-free service of the product, Please read this manual carefully before using the product important:

Appearance and Keystroke Function



- ① Menu
- ② Analog decrease
- ③ Power on/off
- ④ Analog increase
- ⑤ V1/V2 switchover

Specification

- Screen:4.3inch digital (16:9)
- Resolution degree:480(W)xRGBx272(H)
- Power supply:DC12V(DC24V optional)
- Signal: Two way video input,V1/V2 switchover, Blue screen when no signal
- AV2 with trigger wire for reversing
- Operation function:Keystroke+remote control
- OSD language: English(other language optional)
- Appearance dimension:(L)258x(W)85x(T)20mm


Menu Operation Instruction

After power on, the screen will show blue screen and only power & V1/V2 keystroke work when no signal, all keystrokes will work when have signal input.

When you press MENU keystroke by turn, the screen will show “BRIGHT, CONTRAST, COLOR, VOLUME, RESET” .

BRIGHTNESS

When you press MENU, it will show BRIGHT , you can increase or decrease brightness by remote or keystroke.



CONTRAST


When you press MENU again after BRIGHT, it will show CONTRAST, you can increase or decrease contrast by remote or keystroke.



Menu Operation Instruction


COLOR

When you press MENU again after CONTRAST, it will show COLOR, you can increase or decrease brightness by remote or keystroke.



VOLUME

When you press MENU again after COLOR, it will show VOLUME, you can increase or decrease volume by remote or keystroke.



RESET

When you press MENU again after LANGUAGE, it will show RESET, RESET is only for BRIGHT, CONTRAST, COLOR, other setting parameters have no change.